

ON-BOARD DIAGNOSTIC [ENGINE CONTROL SYSTEM (FS)]

01-02B

STEP	INSPECTION		ACTION
13	VERIFY TROUBLESHOOTING OF MISFIRE DTC COMPLETED <ul style="list-style-type: none"> Make sure to reconnect all disconnected connectors. Start engine. Clear DTC from PCM memory using WDS or equivalent. Perform OBD-II DRIVE MODE 1. (See 01-02B-10 Mode 1 (PCM adaptive memory procedure drive mode).) Is same PENDING CODE or stored code of same DTC present? 	Yes	Replace PCM, then go to next step.
		No	Go to next step.
14	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform "After Repair Procedure". (See 01-02B-9 AFTER REPAIR PROCEDURE [FS].) Is there any DTC present? 	Yes	Go to applicable DTC inspection. (See 01-02B-15 DTC TABLE [FS].)
		No	Troubleshooting completed.

DTC P0325 [FS]

A3U010201085W03

DTC P0325	Knock sensor circuit malfunction
DETECTION CONDITION	<ul style="list-style-type: none"> PCM monitors input signal from knock sensor when the following monitoring conditions are met. If PCM does not receive input signal from knock sensor for 5 seconds, PCM determines that knock sensor circuit is malfunctioning. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> — Engine load is above 50% — Engine coolant temperature is above 60 °C {140 °F}. — Engine speed is within 1,500—5,000 rpm. <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). MIL illuminates if PCM detects the above malfunction condition during first drive cycle. PENDING CODE is not available. FREEZE FRAME DATA is available. DTC is stored in the PCM memory.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Knock sensor malfunction Connector or terminal malfunction Open or short to ground circuit between knock sensor connector terminal A and PCM terminal 57 Open or short to ground circuit between knock sensor connector terminal B and PCM terminal 59 Short between two wires of knock sensor

ON-BOARD DIAGNOSTIC [ENGINE CONTROL SYSTEM (FS)]

Diagnostic procedure

STEP	INSPECTION	ACTION	
1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED <ul style="list-style-type: none"> • Has FREEZE FRAME DATA been recorded? 	Yes	Go to next step.
		No	Record FREEZE FRAME DATA on repair order, then go to next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Check for related Service Bulletins availability. • Is any related repair information available? 	Yes	Perform repair or diagnosis according to available repair information. <ul style="list-style-type: none"> • If vehicle is not repaired, go to next step.
		No	Go to next step.
3	INSPECT PCM CONNECTOR TERMINAL <ul style="list-style-type: none"> • Turn ignition key to OFF. • Disconnect PCM connector. • Check for poor connection at terminals 57 and 66 (damaged, pulled-out pins, corrosion, etc.). • Is there any malfunction? 	Yes	Repair terminal, then go to Step 8.
		No	Go to next step.
4	INSPECT KNOCK SENSOR CIRCUITS FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Disconnect knock sensor connector. • Check continuity between the following circuits: <ul style="list-style-type: none"> — Knock sensor female terminal A (harness-side) and PCM terminal 57 (harness-side) — Knock sensor female terminal B (harness-side) and PCM terminal 59 (harness-side) • Is there continuity? 	Yes	Go to next step.
		No	Repair or replace suspected wiring harness, then go to Step 8.
5	INSPECT KNOCK SENSOR CIRCUITS FOR SHORT TO GROUND <ul style="list-style-type: none"> • Check continuity between following circuits: <ul style="list-style-type: none"> — Knock sensor female terminal A (harness-side) and body ground — Knock sensor female terminal B (harness-side) and body ground • Is there continuity? 	Yes	Repair or replace suspected wiring harness, then go to Step 8.
		No	Go to next step.
6	CHECK FOR SHORT CIRCUITS <ul style="list-style-type: none"> • Check continuity between knock sensor female terminals A and B (harness-side). • Is there continuity? 	Yes	Repair or replace suspected harness, then go to Step 8.
		No	Go to next step.
7	CHECK KNOCK SENSOR RESISTANCE <ul style="list-style-type: none"> • Measure resistance between knock sensor terminals (part-side). • Is resistance approx. 560 kilohms? 	Yes	Go to next step.
		No	Replace knock sensor, then go to next step.
8	VERIFY TROUBLESHOOTING OF DTC P0325 COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Turn ignition key to ON (Engine OFF). • Clear DTC from memory using WDS or equivalent. • Start engine. • Access ECT, RPM and LOAD PIDs using WDS or equivalent. • Run vehicle more than 5 seconds in the following conditions: <ul style="list-style-type: none"> — ECT: above 60 °C {140 °F} — RPM: 1,500—5,000 rpm — LOAD: above 50% • Is same DTC present? 	Yes	Replace or reprogram PCM. Then go to next step.
		No	Go to next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform "After Repair Procedure" (See 01-02B-9 AFTER REPAIR PROCEDURE [FS].) • Is there any DTC present? 	Yes	Go to applicable DTC inspection. (See 01-02B-15 DTC TABLE [FS].)
		No	Troubleshooting completed.