

GENUINE MUD FLAP (FRONT)

INSTALLATION AND USER'S INSTRUCTIONS

Thank you for purchasing a genuine Mazda accessory.
Before removal and installation, be sure to thoroughly read these instructions.
Please read the contents of this booklet in order to properly install and use the mud flap.
Your safety depends on it.
Keep these instructions with your vehicle records for future reference.

WARNING

- There are several  **WARNING** and  **CAUTION** sections in this booklet concerning safety when installing or removing the mud flap. Always read and follow them in order to prevent injuries, accidents, and possible damage to the vehicle.
 - ⚠ **WARNING:** Indicates a situation in which serious injury or death could result if the warning is ignored.
 - ⚠ **CAUTION :** Indicates a situation in which bodily injury or damage to the vehicle could result if the caution is ignored.
- For areas indicating the tightening torque in this instruction manual, tighten to the specified torque using a torque wrench. For areas in which the tightening torque is indicated inside parentheses (), the tightening torque is indicated as a reference value, however tightening using a torque wrench is not necessary.
- Do not modify the mud flap.
- Do not install the mud flap in any way other than described in the following instructions.
- If in any doubt, please ask your Mazda dealer to install the accessory in order to prevent errors in installation.
- If you have any questions about the use of the accessory, ask your Mazda dealer for proper advice before using it.
- Mazda and its suppliers are not responsible for injuries, accidents, and damage to persons and property that arise from the failure of the dealer or installer to follow these instructions.
- Be careful not to lose removed parts, and be sure that they are kept free from scratches, grease or other dirt.

PART NAME: MUD FLAP (FRONT)
PART NUMBER: 0000-8H-R10
VEHICLE: CX-5

NOTE

To the dealer


- Please turn over these instructions to the customer after installation.

To the customer

- Keep these instructions after installation. The instructions may be necessary for installing other optional parts or removal of this accessory.
- Should the vehicle or this accessory be resold, always leave these instructions with it for the next owner.

1. PARTS

▼ Installation view



▼ Parts list

NOTE

- Before installation, verify that the kit includes all the following parts and that they are free of dirt, scratches, or damage.

Part	Part name	Qty
	Mud flap (Front) (RH)	1
	Mud flap (Front) (LH)	1
	Clip nut	4
	Bolt	4
	Pull-Rivet	2
	Installation and user's instructions	1

2. BEFORE INSTALLATION

■ REQUIRED TOOLS


- ☆ Screwdriver (Phillips)
- ☆ Torque wrench
- ☆ Socket wrench
- ☆ Soft clean cloth
- ☆ Protective sheet
- ☆ Nipper
- ☆ Isopropyl alcohol (IPA)

⚠ WARNING


- Park the vehicle on a flat, level surface, set the selector lever to P (AT vehicles), apply the parking brake and block the wheels so that the vehicle does not move during installation.

⚠ CAUTION

Use the most appropriate (size, use) tool for each task and perform the may be damaged.



Place the removed parts and kit accessories on a protective sheet to prevent scratches.



⚠ CAUTION

- Always use a torque wrench when tightening bolts and tighten to the specified torque. If tightened outside the specified torque, it could result in poor fit, part damage, or other damage.
- The mud flap (Front) is made of hard plastic. Handle it with care, as it may be deformed or discolored if it contacts solvents such as paint thinner or comes close to flame.


NOTE

- Refer to the applicable Workshop Manual for removal and installation of vehicle parts. Not following the procedures for removal/installation in the Workshop Manual could result in an accident or vehicle malfunction.

3. MUD FLAP (FRONT) INSTALLATION

NOTE


- The figure shows the left side, however, perform the same procedure for the right side.
- Vehicle should be at room temperature prior to installation.




1. Use a soft cloth dampened with IPA (isopropyl alcohol) to clean the surface of the vehicle where the mud flap (front) is to be installed.

2. Cut out existing top, hour glass plastic tab using a nipper.


3. Remove existing pin from fender (middle hole).




4. Align the clips over fender holes, install the kit clip nuts.



5. Temporarily install the kit bolts (2).
Use care to ensure bolts are not cross threaded as breakage could occur.



6. Insert pull-rivet without fully installing to ensure proper alignment of mud flap and wheel well.
Press the mud flap (front) to the over fender installation area to ensure there are no gaps.




7. Remove pull-rivet and remove the flag over the double-sided adhesive tape backings from the mud flap (front) and affix securely.

CAUTION

- Do not separate the taped areas once the tape has adhered, otherwise the subsequent adhesion performance will be greatly reduced.

8. Apply sufficient pressure to the double adhesive tape from the exterior side of the mud flap (front).



9. Re-Install pull-rivet and torque bolts in order shown in the figure on the left while pressing it against the over fender.

NOTE: Ensure hole in the inner fender aligns with the vehicle sheet metal so that the pull-rivet can be fully installed.

**(Tightening torque
Bolt : 0.8—1.2 N·m {8.2—12.2 kgf·cm · 7.1—10.6 in·lbf })**

CAUTION

- Make sure the bolt is tightened securely. Make sure to tighten to the specified torque. If tightened outside the specified torque, the mud flap (front) could be damaged or fall off.

4. CONFIRMATION AFTER INSTALLATION

1. Be sure that there are no excessive gaps.

- If there are any gaps, loosen all the bolts and then retighten them in the order of top, middle, and bottom while pressing the mud flap (front) against the vehicle.

2. Be sure that all bolts are securely tightened.

5. MUD FLAP (FRONT) PRECAUTIONS

CAUTION

- If gasoline, engine coolant, or battery fluid adheres to the painted surface of the resin parts, it will cause discoloration, stains, or paint peeling. Wipe it off with a soft cloth immediately.
- Don't drive through and automatic car wash for 24 hours; it may damage the mud flap (front).
- Do not use car polish containing wax compounds. Otherwise, the surface could be damaged.
- If the vehicle height is lowered due to the vehicle being at maximum passenger or cargo capacity, decrease the vehicle speed when parking on a road shoulder or entering/leaving a road shoulder or bump. Otherwise, the mud flaps (front) could be damaged.

**INSTALLATION
INSPECTION
SHEET**

CX- 5	MUD FLAP (FRONT)
	0000-8H-R10

Inspection after installation

- Inspect the installed / reinstalled parts for the following items.

Inspection Parts	Check Item (O)			
	Clearance/Fit	Scratches / Dirt	Installation / Engagement	Fastener, bolt tightening
Mud flap (Front)	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Over fender	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Installation inspection sheet for mud flap (Front)

Date				
VIN.				
Approved		Checked		Person in charge

The term of validity for this sheet: 36 months