

# Scheduled Maintenance 2016 Mazda CX-5 FWD

Date:

Mileage:

U.S.A. residents - Fixed maintenance interval

Maintenance Interval	Number of months or miles, whichever comes first												
	Months	6	12	18	24	30	36	42	48	54	60	66	72
	×1000 miles	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90
<b>ENGINE</b>													
Drive belts						I						I	
Engine oil & filter	R	R	R	R	R	R	R	R	R	R	R	R	R
<b>COOLING SYSTEM</b>													
Engine coolant*1	FL22 type	Replace at first 120,000 miles or 10 years; after that, every 60,000 miles or 5 years											
Engine coolant level	I	I	I	I	I	I	I	I	I	I	I	I	I
<b>FUEL SYSTEM</b>													
Air filter						R						R	
Fuel lines and hoses*2					I				I				I
Hoses and tubes for emission*2									I				
<b>IGNITION SYSTEM</b>													
Spark plugs	Replace every 75,000 miles												
<b>ELECTRICAL SYSTEM</b>													
Function of all lights	I	I	I	I	I	I	I	I	I	I	I	I	I
<b>CHASSIS and BODY</b>													
Brake lines, hoses and connections					I				I				I
Brake fluid level	I	I	I	I	I	I	I	I	I	I	I	I	I
Disc brakes		I			I				I			I	
Tire (Rotation)*3	Rotate every 7,500 miles												
Tire inflation pressure and tire wear*3	I	I	I	I	I	I	I	I	I	I	I	I	I
Steering operation and linkages					I				I				I
Power steering fluid level	I	I	I	I	I	I	I	I	I	I	I	I	I
Front and rear suspension, ball joints and wheel bearing axial play					I				I				I
Driveshaft dust boots					I				I				I
Bolts and nuts on chassis and body					T				T				T
Exhaust system and heat shields	Inspect every 45,000 miles or 5 years												
All locks and hinges	L	L	L	L	L	L	L	L	L	L	L	L	L
Washer fluid level	I	I	I	I	I	I	I	I	I	I	I	I	I
<b>AIR CONDITIONER SYSTEM</b>													
Cabin air filter					R					R			R

**Chart symbols:**

I: Inspect: Inspect and clean, repair, adjust, or replace if necessary.

R: Replace

L: Lubricate

T: Tighten

**Remarks:**

\*1 Use of FL-22 is recommended when replacing engine coolant. Using engine coolant other than FL-22 may cause serious damage to the engine and cooling system.

\*2 According to state/provincial and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or mileage/kilometer period to ensure long-term reliability.

\*3 The Tire Pressure Monitoring System (TPMS) initialization must be performed so that the system operates normally.