


{ } NAME INDICATED ON FUSE BOX COVER  
 [ ] NOT USED  
 \*: VACANT


T/T

0922-201  
 HORN RELAY(F)




NOTE: SEEN FROM TERMINAL SIDE

0922-202  
 INSTRUMENT PANEL(I)-CLOCK SPRING




(CLOCK SPRING)



TERMINALS OF THIS CONNECTOR ARE INDICATED BY NUMBERS.

0922-203  
 HORN SWITCH(CLOCK SPRING)



TERMINALS OF THIS CONNECTOR ARE INDICATED BY NUMBERS.

0922-204  
 HORN LOW(F)



0922-205  
 HORN HIGH(F)

