

ATOTO RADIO			PAC RP4-MZ11 dial to 7 before connecting				Number of Wires connected together	
PIN NUMBER	Color	Function	Type	Color	Function			
Every wire has been identified by atoto with labels			VC	VC means wires coming from the orange 24 pin connector				
			IC	IC means wires coming from the PAC blue box.				
15	orange	illumination input	VC	orange	white illumination output		2	
13	blue	power antenna output	VC	blue	antenna on input	note: do not use the blue wire on FM antenna adaptor	2	
		SWC headphone jack	IC		SWC headphone plug		1	
16	yellow	12V constant power	VC	yellow	battery 12v		2	
7	RED	ACC POWER	IC	Red	acc power		2	
Reverse camera								
6	pink	reverse camera 12v input	IC	green	reverse output	12v + output activates when car in reverse	3	
8	black	ground	VC	black	ground		4	
?	Female Yellow RCA	Rear view camera input					male Yellow RCA video output	2
With bose amplifier and RCA outputs on harness or radio:								
?	blue white	amplifier on output signal	VC	blue white	amp turn on input		2	
	white	front Left Audio Out RCA jack	VC	white	white RCA plug	Front Left	2	
	red	Front Right Audio Out RCA jack	VC	Grey	Grey RCA plug	Front Right	2	
When no amplifier is present or there is amplifier but no RCA outputs on the harness or atoto radio:								
1	white	Front left +	Line converter		white	white	Front left +	2
2	white black	Front left -	white black		white black	white black	Front left -	
3	Grey	Front Right +	white		Red RCA jack	Grey	Front Right +	2
4	Grey black	Front Right -	white black			Grey black	Front Right -	
9	Purple	Rear Right +	Line converter		white	Purple	Rear Right +	2
10	Purple Right	Rear Right -	white black		White RCA jack	Purple Right	Rear Right -	
11	green	Rear left +	white		Red RCA jack	green	Rear left +	2
12	green black	Rear left -	white black			green black	Rear left -	