












2018 Mazda CX-5  
AUDIO SYSTEM (WITH CENTER DISPLAY / Bose® TYPE AUDIO)

0920-3e

0920-307 FRONT DOOR SPEAKER (LH) 	0920-309 REAR DOOR SPEAKER (LH) 	0920-316 TWEETER (LH) 	0920-319B AUDIO AMPLIFIER 	0920-319C AUDIO AMPLIFIER 
---	---	---	---	---

<b>Front door speaker</b> With Bose®  0920-308 FRONT DOOR SPEAKER (RH)	<b>Rear door speaker</b> With Bose®  0920-310 REAR DOOR SPEAKER (RH)	<b>Tweeter</b>  0920-317 TWEETER (RH)
--	---	---

<b>Front door speaker</b> With Bose® Resistance 	<b>Rear door speaker</b> With Bose® Resistance 	<b>Tweeter</b> Resistance 
--	--	---

<b>Test condition</b> Under any condition	<b>Terminal</b> B C	<b>Resistance (ohm)</b> 2.1
--	------------------------	--------------------------------


<b>Test condition</b> Under any condition	<b>Terminal</b> B C	<b>Resistance (ohm)</b> 3.7
--	------------------------	--------------------------------

<b>Test condition</b> Under any condition	<b>Terminal</b> A B	<b>Resistance (ohm)</b> 3.5—4.5
--	------------------------	------------------------------------

# 2018 Mazda CX-5 AUDIO SYSTEM (WITH CENTER DISPLAY / Bose® TYPE AUDIO)

0920-3e



- : FRONT HARNESS
- : INSTRUMENT PANEL HARNESS
- : REAR HARNESS
- : REAR No.2 HARNESS
- : REAR No.4 HARNESS
- : REAR No.5 HARNESS
- : DOOR HARNESS
- : INTERIOR LIGHT HARNESS
- : INTERIOR LIGHT No.2 HARNESS

